



**Activity**  
Connecting with intelligence

# ThingPark Enterprise All-In-One

---

Installation, Configuration and Operation Guide for v1.0.1

# Content

---

- Requirements
- Installation and upgrade
- Configuration
  - Base station
  - Node-Red MQTT node
  - Device
- MQTT usage (uplink/downlink)
- Advanced tasks

Activity

# Hardware Requirements - UFISPACE

---

- A Ufispac gateway:
  - UFISPACE PICO CELL Enterprise (<https://market.thingpark.com/ufispac-entepriase-pico-cell-thingpark-ready-v1-5-indoor-lorawan-gateway.html>)
  - Or UFISPACE MACRO CELL v1.5
- Characteristics
  - Processor:
    - Model name : ARMv7 Processor rev 2 (v7l)
    - Hardware : Generic AM33XX (Flattened Device Tree)
  - Disk: 4GB
  - Memory : 500MB

# Hardware Requirements - GEMTEK

---

- A GEMTEK LoRa outdoor micro gateway:
  - <https://www.gemteks.com/en/products/lora-iot/gateway#productKkRyJM>
- Characteristics
  - Processor :
    - Model name : ARMv7 Processor rev 0 (v7l), Quad Core
    - Hardware : RK30board
  - Disk: 8GB
  - Memory : 1GB

# Installation Requirements

---

- Installation is manual, you need to have SSH access to the Base Station box, and have the root password
- In case of problems, you might have to use an FTDI cable to directly connect on the box
- You need to have at least 500MB free disk space
- You need to have the relevant distribution package for your hardware:
  - rootfs-patch-tao-1.0.x-fcpico.tar.gz (Ufispac PICO)
  - rootfs-patch-tao-1.0.x-fcmlb.tar.gz (Ufispac MACRO V1.5)
  - rootfs-patch-tao-1.0.x-gemodu.tar.gz (Gemtek)

use the latest  
version

# Installation on UFISPACE PICO/MACRO (1/3)

- Assign BOX\_IP variable to your IP box address

```
export BOX_IP=192.168.1.47
```

- Assign CONF\_FINAL\_PACKAGE\_FILE variable to your package file (without any extension), package file must be on the current folder

- pico :

```
export CONF_FINAL_PACKAGE_FILE=rootfs-patch-tao-1.0 x-fcpico
```

- macro :

```
export CONF_FINAL_PACKAGE_FILE=rootfs-patch-tao-1.0 x-fcmlb
```

- Copy the distribution on your box under /

```
scp $CONF_FINAL_PACKAGE_FILE.tar.gz mlbadmin@$BOX_IP:/'
```



use the latest  
version

# Installation on UFISPACE PICO/MACRO (2/3)

---

- Stop services, decompress and install the package

```
ssh mlbadmin@$BOX_IP " \  
for svc in lrr lrc tao node-red; do \  
  [ -f /etc/init.d/\$svc ] && /etc/init.d/\$svc stop; \  
done; \  
cd /; \  
gunzip $CONF_FINAL_PACKAGE_FILE.tar.gz; \  
tar xvf $CONF_FINAL_PACKAGE_FILE.tar; \  
rm -f $CONF_FINAL_PACKAGE_FILE.tar; \  
/home/actility/tao-system/bootstrap/tao-install.sh; "
```



# Installation on GEMTEK (1/2)

- Assign BOX\_IP variable to your IP box address

```
export BOX_IP=192.168.1.47
```

- Assign CONF\_FINAL\_PACKAGE\_FILE variable to your package file (without any extension), package file must be on the current folder

```
export CONF_FINAL_PACKAGE_FILE=rootfs-patch-tao-1.0x-gemodu
```

use the latest  
version

- Copy the distribution on your box under /

```
scp $CONF_FINAL_PACKAGE_FILE.tar.gz root@$BOX_IP:/
```

- Stop watchdog, decompress, install the package

```
ssh root@$BOX_IP " \  
kill \$(pidof kernel_wdg); sleep 2; echo 'V' > /dev/watchdog; \  
for svc in lrr lrc tao node-red; do \  
  [ -f /etc/init.d/\$svc ] && /etc/init.d/\$svc stop; \  
done; \  
cd /; \  
gunzip $CONF_FINAL_PACKAGE_FILE.tar.gz; \  
tar xvf $CONF_FINAL_PACKAGE_FILE.tar; \  
rm -f $CONF_FINAL_PACKAGE_FILE.tar; \  
/home/activity/tao-system/bootstrap/tao-install.sh "
```

# Installation on GEMTEK (2/2)

---

- At the end, you will get such error messages during firewall startup. They are to be ignored

```
/home/actility/usr/etc/lrr/versions.ini file updated
[OK]
/etc/init.d/firewall: line 124: iptables: command not found
/etc/init.d/firewall: line 125: iptables: command not found
/etc/init.d/firewall: line 128: iptables: command not found
/etc/init.d/firewall: line 129: iptables: command not found
/etc/init.d/firewall: line 136: ip6tables: command not found
/etc/init.d/firewall: line 137: ip6tables: command not found
/etc/init.d/firewall: line 140: ip6tables: command not found
/etc/init.d/firewall: line 141: ip6tables: command not found
```

- Restart the watchdog

```
ssh root@$BOX_IP "/etc/rc.local </dev/null > /dev/null 2>&1 &"
```


# Software upgrade

---

- For an upgrade, you must follow the same steps as for the installation procedure, but you must reboot the box at the end of the procedure

# Login to User Interface (1/2)

- Connect on the box at the following URL :
  - `http://<box ip>:1323`



- Enter password : tao

# Login to User Interface (2/2)


- Check that your base station is up and running
  - on the Base Station TAB
    - Network Connection : CONNECTED
    - LoRaWAN Radio Status : STARTED

STATUS

Network Connection	 CONNECTED
LoRaWAN™ Radio Status	 STARTED
Base Station Restart Time	31/05/21 - 10:24:19

# Change your password (1/2)

- For security reason, it is strongly recommended to change the password
  - on the right side, click on My Account and select Change password



# Change your password (2/2)

- On the old password field, enter "tao"
- Enter the new password on the
  - new password field
  - confirmation password field
- Click save when finished

The screenshot shows a 'Change Password' form with a teal header. It contains three input fields, each with a green checkmark and a toggle icon (an eye). The first field is labeled 'Old password' and contains three dots. The second field is labeled 'New password' and contains seven dots. The third field is labeled 'Confirmation password' and contains seven dots. Below the fields are two buttons: 'CANCEL' and 'SAVE'.

- The initial password is "tao"
- On password change, the minimum password length is 8 chars, it must be a standard linux password


# Base station configuration (1/2)

- You can now configure your Base station, return to the "TPE All In One" GUI, and scroll down to the "Configuration" widget:



- You can change the RF-Region settings


- click on the "PEN" icon 
- in the dropdown, select your new region, and click on the validation icon when finished 



- Wait about 1 minute for the Base Station to reconfigure, you can receive temporary errors during that phase

## Base station configuration (2/2)

- Set Antenna Gain and Cable loss as per the following table:




CONFIGURATION

RF-Region ⓘ  
EU 863-870MHz (8 channels) [edit]


RF antenna gain ⓘ 0 dB [edit]      RF antenna cable loss ⓘ 0 dB [edit]

	Antenna Gain	Cable loss
Ufispaco pico (external antenna)	1.5 dBi	0 dB
Ufispaco enterprise (internal antenna)	1.4 dBi	0 dB
Ufispaco macro v1.5 & Gemtek outdoor micro	Depends on antenna model	Typically ~ 0.5 dB but depends on installation


# Node-RED : MQTT configuration (1/5)






- Connect on node-red to configure the MQTT server :
  - on the Devices / List TAB, click on the node-red icon 




# Node-RED : MQTT configuration (2/5)




- Click on node-red Sign in button, and eventually sign in again with your password



# Node-RED : MQTT configuration (3/5)



- Double click the "MQTT /uplink-topic" node and configure the MQTT node

A screenshot of the "Edit mqtt out node" configuration dialog. The dialog has a title bar with "Delete", "Cancel", and "Done" buttons. Below the title bar is a "Properties" section with a gear icon, a document icon, and a refresh icon. The settings are: Server: mqtt (dropdown), Topic: /uplink-topic (text input), QoS: 2 (dropdown), Retain: false (checkbox), and Name: MQTT /uplink-topic (text input). A yellow tip box at the bottom says: "Tip: Leave topic, qos or retain blank if you want to set them via msg properties." There is also a small edit icon (pencil) to the right of the Name field.

- You can change here the standard MQTT settings
  - Topic : the topic where you will receive the uplinks
  - QoS, Retain : standard MQTT attributes
  - Name : the display name of the node



# Node-RED : MQTT configuration (4/5)




- Click on the server "pen" icon to configure the MQTT server

A screenshot of the Node-RED MQTT configuration dialog box. The title bar reads "Edit mqtt out node > Edit mqtt-broker node". It has "Delete", "Cancel", and "Update" buttons. The "Properties" section shows "Name" set to "mqtt". The "Connection" tab is active, showing "Server" as "mqtt.test.com" and "Port" as "1883". There are checkboxes for "Enable secure (SSL/TLS) connection" (unchecked), "Use clean session" (checked), and "Use legacy MQTT 3.1 support" (checked). The "Client ID" field is set to "Leave blank for auto generated". The "Keep alive time (s)" is set to "60".


- You can change here the main server attributes
  - server address, server security, server secure connection, ...
- You must click "Update" to apply your configuration
- And click also "Done" when you also want to save the MQTT node configuration




# Node-RED : MQTT configuration (5/5)



- Do the Same for the "MQTT /downlink-topic" node, server configuration is global to both nodes
- After you have done all node-red reconfiguration, you must click on "Deploy" to push your new flow on the server



- After few seconds, you should see that your MQTT nodes get connected



# Node-RED : BACnet / Modbus




- On node-red, you may use BACnet/IP nodes in your workflows
- And you may also use MODBUS TCP/IP nodes
  - For the Modbus server node, you can only use tcp port 10502 or tcp port 11502 : they are not filtered and therefore can be accessed externally by Application Server



# Node-RED : Usage

---



## WARNING :

Use of Node-Red nodes in "server" mode (e.g. modbus server) - with regular polling from external client applications - has not been benchmarked by Actility. Server mode may have negative impacts on TPE-All-in-One performances. Such potential impact on performance remains under the entire responsibility of the TPE Partner.

# Device configuration (1/2)

- You can now create your first device (OTAA example)
  - On Devices / Create TAB, click save when finished

**Enter Your Device Informations\***

Name\* 



Manufacturer\*



Model\*



DevEUI\* 



Activation mode\* 



AppKey\* 



---

## Device configuration (2/2)

- On the Devices / List TAB, your device is created

- the device is created (orange status)
- DevEUI is presented
- DevAddr not yet assigned (OTAA)



1 DEVICE(S) Filter by name or DevEUI


	Name	DevEUI	DevAddr	Last Packet	Packets	SNR	SF	
	otaa device	70-B3-D5-32-60-00-1A-75		Never				...

- To update the list

- You can update the list just by changing the screen, all screens are refreshed as soon as they are re-displayed (change from Devices / List to Devices / Create and return to Devices / List)

- You can see that after few uplink packets, your list is updated

- the device is connected (green status)
- last packet gets a timestamp
- DevAddr is assigned (OTAA)
- Packets represent the uplink counter
- SNR, SF ...



1 DEVICE(S) Filter by name or DevEUI

	Name	DevEUI	DevAddr	Last Packet	Packets	SNR	SF	
	otaa device	70-B3-D5-32-60-00-1A-75	02-85-F7-90	23/12/20 - 16:48:42	1	9.5 dB	SF7	...

# Device configuration / mass import (1/3)

You can also use the mass import feature to import multiple devices in one click

**IMPORTING DEVICE(S)**

**Prepare Your Device Import File**

Your file must be a well-formatted .csv file strictly compliant with the sample below. For more information, see [User Guide](#).

[MODEL LISTS](#) [SAMPLE FILE](#)

**Upload Your Device Import File**

Browse to select your file.

Click the button to browse... 

**IMPORT**

- Follow the "SAMPLE FILE" link to understand the csv format
- Follow the "MODEL LISTS" link to find the "Profile ID" that corresponds to your device profile

## Device configuration / mass import (2/3)

- Create a csv (comma separated value) file, you should have something like this at the end (OTAA and ABP device sample) :

```
CREATE_OTAA,70B3D53260001A75,,LORA_GenericA.1.0.2a_ETSI_Rx2-SF12,,31FD21B72E9CF9F861CF27450D4160E6,,device_1
```

```
CREATE_ABP,000000000539B181,0539B180,LORA_GenericA.1.0.2c_ETSI,2B7E151628AED2A6ABF7158809CF4F3C,2B7E151628AED2A6ABF7158809CF4F3C,,device_2
```

- Save the file in utf8 format when using a simple text editor
- Click on the  to open the import dialog box and select your file
- Click « Import »

Browse to select your file.


device\_import\_sample-tao.csv



IMPORT

## Device configuration / mass import (3/3)

- When everything is done, and you have no error, you can directly return to the device list and start working with your devices
- In case of errors, you get a page that summarizes these errors, ordered by line number



The screenshot shows a web interface for device import. At the top, a teal header reads "Import 2 Device(s)". Below it, a progress bar indicates "100%". The main content area displays a summary: "1 device(s) successfully imported" in green and "1 device(s) failed to import with the following errors:" in red. Below this is a section titled "ERROR DETAILS" with a download icon. It contains a table with three columns: "Line #", "DevEUI", and "Error". The table has one row with the following data: Line # 1, DevEUI 00-00-00-00-05-39-B1-81, and Error DevEUI already exists. At the bottom of the page, there is a teal button labeled "GO TO DEVICES LIST".

Line #	DevEUI	Error
1	00-00-00-00-05-39-B1-81	DevEUI already exists

- You can now correct the file, and re-import the corrected devices

# MQTT usage : Uplink

- On the MQTT server, you can subscribe to the "/uplink-topic" topic, and verify that you get your packets

```
[root@tools mosquitto]# mosquitto_sub -t /uplink-topic -h localhost
```

```
{"DevEUI_uplink":{"Time":"2020-12-23T15:51:48.604+00:00","DevEUI":"70B3D53260001A75","FPort":2,"FCntUp":2,"MType":4,"FCntDn":3,"payload_hex":"cafe","mic_hex":"459b05c6","Lrcid":"0000000F","LrrRSSI":-58,"LrrSNR":9.75,"SpFact":7,"SubBand":"G2","Channel":"LC5","DevLrrCnt":1,"Lrrid":"FFFFFFFF","Late":0,"LrrLAT":0,"LrrLON":0,"Lrrs":{"Lrr":[{"Lrrid":"FFFFFFFF","Chain":0,"LrrRSSI":-58,"LrrSNR":9.75,"LrrESP":-58.43726}]},"CustomerID":"tao","ModelCfg":"0","InstantPER":0,"MeanPER":0,"DevAddr":"0285F790","TxPower":14,"NbTrans":1,"Frequency":867.3,"DynamicClass":"A"}}
```

...

# MQTT usage : Downlink

---

- You can also send downlink packets using the "downlink-topic" topic

```
[root@tools mosquitto]# mosquitto_pub -t /downlink-topic -h localhost -m  
"{\"DevEUI_downlink\":{\"DevEUI\":\"70B3D53260001A75\",\"FPort\":\"2\",\"Confirmed\":\"1\",\"FlushDownlinkQueue\":\"1\",\"payload_hex\":\"1238\"}}"
```




# System Backup (1/4)

---

- It is necessary to regularly create a backup archive of your gateway:
    - Before / after node-red flow changes
    - After new device creations
    - Before / after LRR modifications (via Suplog)
    - Before / after system upgrades (upgrade version > 1.0.0), to support potential rollback situations
- This will ensure that you will be able to restore the gateway if something went wrong

# System Backup (2/4)

- To create a backup file :
  - Go to "Advanced Management"
  - Click on the "Backup" button, then click "Backup" again on the popup



- The backup file is automatically downloaded on your browser

# System Backup (3/4)

- After the backup is executed with success, a persistent link is generated :
  - it indicates the age of the last backup
  - it allows you to download the file later-on, but it is highly recommended to save the backup file in an alternative storage location

BACKUP AND RESTORE

**Backup the current configuration** [Last backup 9 minutes ago](#)

Exports an archive containing the current base station, devices and system configurations for future restoration.

**Restore a previous configuration**

Imports an archive to restore a previously backed up configuration.

## System Backup (4/4)

---

- The backup file consists of :
  - LRC database (FDB\_lora)
  - Node-Red data folder (flows, credentials)
  - TPE-All-in-One (TAO) data folder (secret key)
  - A complete LRR backup (specific LRR procedure), including the network configuration changes provided through Suplog
  - TAO release version file
- Note: passwords are not included in the archive


# System Restore (1/3)

---


- Restore can only be executed on the same TAO version and the same hardware model (full restoration of LRR requires the same hardware model)
- It allows you for example to rebuild a gateway after a hardware failure
  1. install the same TAO version on an identical hardware model
  2. restore the archive content on that gateway
- Be careful, as the network configuration is restored, you might lose your gateway, it is then recommended to make sure that the gateway is correctly configured (identically as the backup)
- A full restore duration is around 3mn

# System Restore (2/3)

- To restore a backup :
  - Go to "Advanced Management"
  - Click on the Restore button
  - On the popup
    - Click on "I understand the consequences of the restore"
    - Click on the  and pickup you backup file



- Click "Restore"



## Restore a backup

- All the content of the **base station will be erased** and replaced by the content of the provided backup archive.
- The restore **cannot be undone**.

- During the restore process, the network server will restart and few packets may be lost.
- Depending on the restored network configuration, the base station might change its IP address.

I understand the consequences of the restore

Backup archive

backup-2021-05-28.tgz



CANCEL

RESTORE

## System Restore (3/3)

- During restoration, a waiting screen is displayed, and the GUI is locked



- Any attempt to navigate is blocked, all new login will be redirected to this same page
- After restoration, all required services are restarted and the user can navigate again

# Advanced tasks : Services

---

- TAO is composed of a standard LRR with its standard services, most important one is :
  - `/etc/init.d/lrr`
- 3 new services are added
  - `/etc/init.d/lrc {start | stop | status | restart}`
    - LRC server
  - `/etc/init.d/tao {start | stop | status | restart}`
    - tao server, written in GO, serving the angular GUI
  - `/etc/init.d/node-red {start | stop | status | restart}`
    - node-red server

# Advanced tasks - WARNING

---

- **Important**

- It is not allowed to modify any configuration files located under `/home/activity/usr/etc...` (except for temporary tests)
- All these modifications will be lost after an upgrade

# Advanced tasks : Access to logs (1/3)

- All logs are stored in a tmpfs in-memory space
  - log storage root path :
    - ufi space : /var/volatile/log
    - gemtek : /dev/shm/log
  - for each service, a dedicated folder is created
    - < log storage root path > /\_LRCLOG
    - < log storage root path > /\_LRRLOG
    - < log storage root path > /\_NODEREDLOG
    - < log storage root path > /\_TAOLOG
- This is achieved through links (ufi space example)

```
am335x-evm:/# ls -l /home/actility/var/log/
```

```
lrwxrwxrwx 1 root root 25 Jan 5 11:36 lrc -> /var/volatile/log/_LRCLOG
lrwxrwxrwx 1 root root 25 Jan 5 11:36 lrr -> /var/volatile/log/_LRRLOG
lrwxrwxrwx 1 root root 29 Jan 5 11:36 node-red -> /var/volatile/log/_NODEREDLOG
lrwxrwxrwx 1 root root 25 Jan 5 11:36 tao -> /var/volatile/log/_TAOLOG
```

## Advanced tasks : Access to logs (2/3)

---

- tmpfs space
  - ufi space PICO/MACRO : 100 MB
  - gemtek : 500 MB
- Log levels are kept very low
  - LRR (/home/activity/usr/etc/lrr/lrr.ini) :
    - level=1, debug=1, size=10000000 (10MB)
  - LRC (/home/activity/usr/etc/lrc/lrc.ini) :
    - level=1, debug=1, size=10000000 (10 MB)
  - TAO (/home/activity/usr/etc/tao/configs/tao\_server\_config.yaml) :
    - level: WARN, maxSize=10 #megabytes
  - node-red : (/home/activity/usr/etc/node-red/settings.js) :
    - level : 'error', size=10000000 (10 MB)

## Advanced tasks : Access to logs (3/3)

---


- Log level modification
  - For Irr, tao, node-red, you must connect on the base station, and modify the configuration files and then, restart the corresponding service
  - For Irc, you can do the same or dynamically through a telnet admin session (telnet 0 2009)
- All logs are stored in memory, they are copied on disk every day in /home/activity/traces

# Advanced tasks – Suplog (1/2)

- Preliminary : for putty users, you must configure "Allow ACS line drawing in UTF" to get nice rendering
- Connect on suplog using ssh (password is the one you use to connect on tao)

```
ssh support@$BOX_IP
```

- To navigate inside the tool :
  - <tab>, <arrow right> : move to action buttons, then return to the initial position, navigate inside forms
  - <arrow up> / <arrow down> : change position in menus, navigate inside forms
  - <enter> : select a menu item, validate an action
  - <space> : activate/deactivate a choice inside forms




## Advanced tasks – Suplog (2/2)

---

- Warning : some menu configurations are not supported or irrelevant in TPE All In One context :
  - Identifiers
  - Radio configuration
  - System configuration / PKI
  - System configuration / Backhaul
  - Service
  - Troubleshooting



# Suplog DHCP -> Static IP (1/3)

- The gateway is originally configured for ethernet with DHCP, follow these steps to configure a fix IP address
  - select System configuration, press <enter>
  - select Network, press <enter>
  - select Network interfaces, press <enter>
  - you can then configure your interface settings, use <tab> to navigate through the fields
    - Active, should have an [X]
    - DHCP activated, should be deactivated : [ ]
    - IP address, Netmask, Broadcast, Gateway, DNS list must be configured
    - Move to the Confirm button, Press <Enter>




# Suplog DHCP -> Static IP (2/3)

- select Back button, press <enter>
- select Apply, press <enter>
- you are now invited to wait, the gateway is now reconfiguring everything, but as you have changed the ip address, your console is no more on the right location



## Suplog DHCP -> Static IP (3/3)

- After the configuration is applied, you must wait around **1 minute** before connecting to the new IP address (you will not be able to commit the configuration before this delay), you also have 15 minutes to commit your changes, if you don't commit, the configuration will be automatically rolled back
  - connect a new suplog session to the new IP address
  - select System configuration, press <enter>
  - select the Commit button, press <enter>




## Suplog Eth -> WiFi mode [PICO] (1/6)

---

- The gateway is originally configured for ethernet with DHCP, follow these steps to configure the WiFi mode instead of ethernet
- Five steps are required
  - Configure your WiFi credentials
  - Deactivate eth0
  - Activate wlan0
  - Apply the configuration
  - Commit the configuration




# Suplog Eth -> WiFi mode [PICO] (2/6)

- Step 1/5 : enter your WiFi credentials
  - select System configuration, press <enter>
  - select Network, press <enter>
  - select WiFi, press <enter>
  - you can then configure your WiFi settings, use <tab> to navigate through the fields
    - Available, should have an [X]
    - SSID, enter your SSID
    - Security, enter your security algorithm, press <enter>, when finished to validate your choice
    - Key, enter your security key, press <enter>,
    - Confirm, press <enter>
  - Select Back button to return to the System configuration




# Suplog Eth -> WiFi mode [PICO] (3/6)

- Step 2/5 : deactivate eth0
  - select IP failover, press <enter>
  - Interface should be (\*) eth0
  - move to Status, select not-used and press <enter>
  - stay on this form for the next step !



# Suplog Eth -> WiFi mode [PICO] (4/6)

- Step 3/5 : activate wlan0
  - move to Interface, and select wlan0 (<space>)
  - Interface should be (\*) wlan0
  - move to Status, select primary and press <enter>
  - move to Confirm, press <enter>
  - on the OK button, press <enter>
  - you are now back to the System configuration menu



# Suplog Eth -> WiFi mode [PICO] (5/6)

- Step 4/5 : apply your configuration
  - move to Apply, and press <enter>
  - press <enter> on the Confirm button
  - Please wait, you will now loose your network connection, you need to find the WIFI address
  - After the configuration is applied, you have 15 minutes to commit your changes, if you don't commit, the configuration will be automatically rolled back

```
System configuration
Last modifications : 2021-01-13 16:19:43
Modifications status : Modified
Time before rollback : No rollback planned

Network
IP failover
PKI
Backhaul

Apply Rollback Cancel
```

```
System configuration
Last modifications : 2021-01-13 16:19:43
lrr must be restarted
Please confirm or cancel...

Confirm Cancel
```

```
System configuration
Last modifications : 2021-01-13 16:19:43
Modifications status : Modified
Time before rollback : No rollback planned

Network
IP failover
PKI
Backhaul

Apply Rollback Cancel
```

```
Arago 2015.05 am335x-evm /dev/tty00
am335x-evm login: mlbadmIn
Password:
am335x-evm:~# ifconfig
eth0      Link encap:Ethernet  HWaddr 38:08:3C:26:9E:E8
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:67683 errors:0 dropped:0 overruns:0 frame:0
          TX packets:33998 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:85547210 (81.5 MiB)  TX bytes:8521581 (8.1 MiB)
          Interrupt:56

lo        Link encap:Local Loopback
          inet addr:127.0.0.1  Mask:255.0.0.0
          UP LOOPBACK RUNNING  MTU:65536  Metric:1
          RX packets:5128 errors:0 dropped:0 overruns:0 frame:0
          TX packets:5128 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:0
          RX bytes:3345515 (3.1 MiB)  TX bytes:3345515 (3.1 MiB)

wlan0    Link encap:Ethernet  HWaddr A8:10:87:14:93:A2
          inet addr:192.168.1.23  Bcast:192.168.1.255  Mask:255.255.255.0
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:118 errors:0 dropped:0 overruns:0 frame:0
          TX packets:149 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:14568 (14.2 KiB)  TX bytes:16592 (16.2 KiB)

am335x-evm:~#
```

Activity



## Suplog Eth -> WiFi mode [PICO] (6/6)

---

- Step 5/5 : commit your configuration
  - See next slide


# Suplog - Commit configuration

- Every time you apply a new configuration, ThingPark All In One will keep this configuration for 15 minutes, and will automatically roll back if you don't commit your changes
- you have to commit the configuration to keep it permanently
  - you must return to the System configuration menu
  - Modification Status should be : Applied
  - Time before rollback is also displayed
  - You now have to select Commit and press <enter>
  - The screen will change to reflect the new Modification Status : Committed




# Suplog - Restore configuration

- If you want to restore your previous configuration manually rather than waiting for the automatic rollback
  - select System configuration, press <enter>
  - Modification Status should be : Applied
  - Time before rollback is displayed
  - Select Rollback and press <enter>
- Note : Once a configuration is committed, it cannot be rolled back



# Suplog - Change NTP Servers

- If you want to change your NTP servers
  - Select System configuration, press <enter>
  - Select Network and press <enter>
  - Select NTP and press <enter>
  - Change the NTP servers list
  - Move to Confirm, press <enter>
  - Move to Back, press <enter>
  - Move to Apply, press <enter>
  - After reconfiguration, commit your configuration, see [Suplog - Commit configuration](#)



# Advanced tasks - Direct access to Node-Red flow

- In case you encounter issues with Node-Red configuration, making Node-Red UI unreachable (e.g. infinite loop that consume all node CPU) and you have no backup file
  - You may directly connect on the box using the node-red user (password is the one you use to connect on tao)
    - `ssh node-red@$BOX_IP`
  - Enter the node-red-data folder
    - `cd /home/actility/node-red-data/`
  - You can edit flows.json and correct the file
  - You can now kill -9 the node-red process, it will be automatically restarted, take care to only kill the "node-red" process



```
am335x-evm:~$ ps | grep node-red
```

```
3768 root      1464 S      {S99node-red} /bin/sh /etc/rc5.d/S99node-red _respawnService
3822 node-red   2600 S      su -c /opt/node/bin/node /home/actility/node-red/node_modules/node-red/red.js --settings /home/actility/usr/etc/node-red/settings.js node-red
3838 node-red  131m S      node-red
```



# Advanced tasks – Access via serial port

- You may connect to the serial port using an FTDI cable
  - black : GND
  - yellow : TX
  - orange : RX
- Speed (baud): 115200, Data bits: 8, Stop bits: 1, Parity: None, Flow control: XON/XOFF



THANK YOU



Actility